


NOTICE: Information About Batteries Used in Keyless Entry System Transmitters (Original Equipment Manufacturer Parts)

☐ **The scope of this document**

The following shall be applicable from February 2027.

☐ **Replacing battery**

1. Remove the lower cover by prying the flat-head screwdriver into the dent of the side.
2. Remove the battery cover.
3. Remove the battery.
4. Insert a new battery into the module with the “+” terminal facing up.
5. Fix the battery cover and fix the lower cover to the upper cover for sure.



 NOTICE

- *The battery lifetime may differ depending on the usage conditions.
- *Risk of explosion if the battery is replaced by an incorrect type.
- *Replace battery with the same type.

☐ **Battery Information**

Manufacturer information for battery used in the keyless entry system is as follows.

For details, please refer to the battery manufacturer website via the URL or QR code listed below.

Trade Name: Panasonic

Panasonic Energy Co., Ltd.

Address: 1-1 Matsushita-cho, Moriguchi City, Osaka
570-8511, Japan

URL : <https://www.panasonic.com/global/energy.html>



☐ **CAUTION: Ingestion hazard.**

- * This product contains a coin / button cell battery.
- * Do not ingest the battery.
- * If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- * Keep new and used batteries away from children.
- * If the battery compartment does not close securely, stop using the product and keep it away from children.
- * If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

☐ **CAUTION: Risk of explosion or leakage of flammable liquid or gas.**

- * Do not use in /store in /bring into environment of extremely high temperature or extremely low pressure due to the very high altitude.
- * Do not attempt to burn, crush, or cut used battery.
- * Do not charge. Charging is dangerous as it may cause leakage, heat generation, explosion, or fire.